



Montagehandleiding Membranen Instructions de montage membranes Reparing Diaphragms



1

1° Markeer de positie van het membraan op de gasschuif.
Marquez la position de l'ergot sur le boisseau.
Put a mark for the position of the diaphragm on the slider



2

2° Knip de bovenste plastic ring middendoor.
Coupez la bague plastique supérieure.
Cut the upper ring.



3

3° Demonteer de gasschuif.
Démontez le boisseau.
Undo the slider from the old diaphragm.



4

4° Doe een test om de membraan juist te positioneren.
Faites un essai de positionnement de la membrane.
Do a test for the good position of the diaphragm.



5

5° Breng een paar druppeltjes van de meegeleverde lijm aan op de gasschuif.
Mettez quelques gouttes de la colle livrée avec le kit.
Put a few drops of glue on the upper side of the slider



6

6° Droogtijd 8 uur voor de montage.
Temps de séchage est de 8 heures avant le remontage
Dessication time is around 8 hours. So install it properly.

